


**RUNNER II R1 A/B RUNNER II R1 C/D**  
**RUNNER II R2 A/B RUNNER II R2 C/D**





WWW.AGURI.EU





LIT Pritvirtinimo instrukcijos  
 PL Instrukcja montażu  
 CZ Návod na montáž  
 SK Návod na montáž  
 SLO Navodila za pritrjevanje  
 HR Uputa za sastavljanje  
 HU A felszerelés módja  
 GR Οδηγίες συναρμολόγησης  
 UA Інструкція з монтажу  
 BY Інструкцыя па мантажы  
 RO Instrucțiuni de montare  
 TK Uydurma talimat  
 N Monteringsveiledning

I Istruzioni per il montaggio  
 GB Fitting instructions  
 F Instructions de montage  
 D Montageanleitung  
 E Instrucciones de montaje  
 NL Montage-instructies  
 DK Monteringsinstruktion  
 FIN Asennusohje  
 S Monteringsanvisning  
 RU Инструкция по установке  
 PT Instruções de Montagem  
 EST Paigaldusjuhend  
 LAT Stiprināšanas instrukcija



## RUNNER A/B





CHECK  
APPLICATION

A

B



## RUNNER C/D





CHECK  
APPLICATION


C

D







1 - 2 - 3 - 4




1 - 2 - 3 - 4





1 - 2 - 3 - 4











1 - 2 - 3 - 4



CHECK





### OPTIONAL ACCESSORIES

